

STAINLESS STEEL



| 8" BACKSPLASH MOUNT FAUCET WITH SWING SPOUT, EZ-INSTALL ADAPTERS | | | |
|--|-------|----------|--|
| HANDLE TYPE | | CATEGORY | DESCRIPTION |
| LEVER | WRIST | | |
| 61204 | 61212 | SS | 8" BS Mount Faucet, 6" Swing Spout, EZ-Install Adapters |
| 61077 | 61085 | SS | 8" BS Mount Faucet, 8" Swing Spout, EZ-Install Adapters |
| 60933 | 60941 | SS | 8" BS Mount Faucet, 10" Swing Spout, EZ-Install Adapters |
| 60801 | 60828 | SS | 8" BS Mount Faucet, 12" Swing Spout, EZ-Install Adapters |
| 60674 | 60682 | SS | 8" BS Mount Faucet, 14" Swing Spout, EZ-Install Adapters |
| 60542 | 60550 | SS | 8" BS Mount Faucet, 16" Swing Spout, EZ-Install Adapters |



| 8" BACKSPLASH MOUNT FAUCET WITH DOUBLE JOINTED SWING SPOUT, EZ-INSTALL ADAPTERS | | | |
|---|-------|----------|--|
| HANDLE TYPE | | CATEGORY | DESCRIPTION |
| LEVER | WRIST | | |
| 61131 | 61158 | SS | 8" BS Mount Faucet, 6" Swing Spout, 7"DJ, EZ-Install Adapters |
| 61018 | 61026 | SS | 8" BS Mount Faucet, 8" Swing Spout, 7"DJ, EZ-Install Adapters |
| 60879 | 60887 | SS | 8" BS Mount Faucet, 10" Swing Spout, 7"DJ, EZ-Install Adapters |
| 60720 | 60747 | SS | 8" BS Mount Faucet, 12" Swing Spout, 7"DJ, EZ-Install Adapters |
| 60607 | 60615 | SS | 8" BS Mount Faucet, 14" Swing Spout, 7"DJ, EZ-Install Adapters |
| 60461 | 60488 | SS | 8" BS Mount Faucet, 16" Swing Spout, 7"DJ, EZ-Install Adapters |



| 8" BACKSPLASH MOUNT FAUCET WITH SWIVEL/RIGID GOOSENECK, EZ-INSTALL ADAPTERS | | | |
|---|-------|----------|---|
| HANDLE TYPE | | CATEGORY | DESCRIPTION |
| LEVER | WRIST | | |
| 61441 | 61468 | SS | 8" BS Mount Faucet, 6" Swivel/Rigid Gooseneck Spout, EZ-Install Adapters |
| 61263 | 61271 | SS | 8" BS Mount Faucet, 12" Swivel/Rigid Gooseneck Spout, EZ-Install Adapters |



lever handles



wrist handles




8" BACKSPLASH MOUNT FAUCET WITH CONTROL SWING SPOUT, EZ-INSTALL ADAPTERS

| HANDLE TYPE | | CATEGORY | DESCRIPTION |
|-------------|-------|----------|--|
| LEVER | WRIST | | |
| 65471 | 65528 | SS | 8" BS Mount Faucet, 12" Control Swing Spout, EZ-Install Adapters |



8" BACKSPLASH MOUNT FAUCET WITH DOUBLE JOINTED CONTROL SWING SPOUT, EZ-INSTALL ADAPTERS

| HANDLE TYPE | | CATEGORY | DESCRIPTION |
|-------------|-------|----------|--|
| LEVER | WRIST | | |
| 65552 | 65587 | SS | 8" BS Mount Faucet, 12" Control Swing Spout, 7" DJ, EZ-Install Adapters |
| 65617 | 65641 | SS | 8" BS Mount Faucet, 12" Control Swing Spout, 12" DJ, EZ-Install Adapters |



FISHER EZ-Install Adapters speed up replacement by allowing FISHER Backsplash Mount Faucets to be installed without the need to remove the backsplash from the wall. There's an EZ-Install Adapter for practically any existing faucet

FISHER Taking the lead on *zero lead* compliance

Fisher Manufacturing Company • PO Box 60 • Tulare, CA 93275 • 800-421-6162 • noleadfaucet.com